

Murata™ Obtuse Corner

TO MAINTAIN WALL BOND PATTERN, START LAYING FROM CORNER OUTWARDS

